

QM5389V

Voltage type outdoor aluminum wind speed and direction integrated sensor

User Manual

File Version: V23.2.26



QM5389V using the standard ,easy access to PLC. DCS and other instruments or systems for monitoring wind speed,conductivity state quantities. The internal use of high-precision sensing core and related devices to ensure high reliability and excellent long-term stability, can be customized



RS232,RS485,CAN,4-20mA,DC0~5V\10V,ZIGBEE,Lora,WIFI,GPRS and other output methods.

Technical Parameters

Technical parameter	Parameter value
Brand	TRANBALL
Wind speed range	0~30m/s
Start wind	0.2m/s
Wind speed accuracy	$\pm 3\%$
Shell material	aluminum
Wind direction range	0~360°
Wind direction resolution	22.5°
Power	DC12~24V 1A
Running temperature	-30~85℃


Product Selection

Product DesignDC0-5V,DC0-10VMultiple output methods, the products are divided into the following models depending on the output method.

Product model	output method
QM5389V5	DC0-5V
QM5389V10	DC0-10V

Product Size







How to wiring?




※ NOTE: WHEN WIRING, CONNECT THE POSITIVE AND NEGATIVE POLE OF THE POWER SUPPLY FIRST, AND THEN CONNECT THE SIGNAL WIRE

Application solution



■ Application scheme



How to use?



Product List



INTEGRATED SENSOR FOR WIND SPEED AND DIRECTION (EXCLUDING ANY OTHER ACCESSORIES)

1. wind speed and DC0-5Vvoltage computing relationship

For example, the range is 0~30m/s, the analog output is 0~5V DC0-5Vvoltage signal, wind speed and DC0-5Vvoltage The calculation relationship is as shown in the formula: C = (A2-A1) * (X-B1) / (B2-B1) + A1, where A2 is wind speed range upper limit, A1 is the lower limit of the range, B2 is DC0-5Vvoltage output range upper limit, B1 is the lower limit, X is the currently read wind speed value, and C is the calculated DC0-5Vvoltage value. The list of commonly used values is as follows:

DC0-5Vvoltage(V)	wind speedValue (m/s)	Calculation Process
0	0.0	(30-0)*(0-0)÷(5-0)+0
1	6.0	(30-0)*(1-0)÷(5-0)+0
2	12.0	(30-0)*(2-0)÷(5-0)+0
3	18.0	(30-0)*(3-0)÷(5-0)+0
4	24.0	(30-0)*(4-0)÷(5-0)+0
5	30.0	(30-0)*(5-0)÷(5-0)+0



As shown in the above formula, when measuring 2.5V, current DC0-5Vvoltage is 15m/s.

2. conductivity and DC0-5Vvoltage computing relationship

For example, the range is $0\sim360^\circ$, the analog output is $0\sim5V$ DC0-5Vvoltage signal, conductivity and DC0-5Vvoltage The calculation relationship is as shown in the formula: C = (A2-A1) * (X-B1) / (B2-B1) + A1, where A2 is conductivity range upper limit, A1 is the lower limit of the range, B2 is DC0-5Vvoltage output range upper limit, B1 is the lower limit, X is the currently read conductivity value, and C is the calculated DC0-5Vvoltage value. The list of commonly used values is as follows:

DC0-5Vvoltage(V)	conductivityValue (°)	Calculation Process
0	0.0	(360-0)*(0-0)÷(5-0)+0
1	72.0	(360-0)*(1-0)÷(5-0)+0
2	144.0	(360-0)*(2-0)÷(5-0)+0
3	216.0	(360-0)*(3-0)÷(5-0)+0
4	288.0	(360-0)*(4-0)÷(5-0)+0
5	360.0	(360-0)*(5-0)÷(5-0)+0

As shown in the above formula, when measuring 2.5V, current DC0-5Vvoltage is 180°.

1. wind speed and DC0-10Vvoltage computing relationship

For example, the range is $0\sim30$ m/s, the analog output is $0\sim10$ V DC0-10Vvoltage signal, wind speed and DC0-10Vvoltage The calculation relationship is as shown in the formula: C = (A2-A1)*(X-B1)/(B2-B1) + A1, where A2 is wind speed range upper limit, A1 is the lower limit of the range, B2 is DC0-10Vvoltage output range upper limit, B1 is the lower limit, X is the currently read wind speed value, and C is the calculated DC0-10Vvoltage value. The list of commonly used values is as follows:

DC0-10Vvoltage(V)	wind speedValue (m/s)	Calculation Process
0	0.0	(30-0)*(0-0)÷(10-0)+0
1	3.0	(30-0)*(1-0)÷(10-0)+0
2	6.0	(30-0)*(2-0)÷(10-0)+0
3	9.0	(30-0)*(3-0)÷(10-0)+0
4	12.0	(30-0)*(4-0)÷(10-0)+0
5	15.0	(30-0)*(5-0)÷(10-0)+0
6	18.0	(30-0)*(6-0)÷(10-0)+0
7	21.0	(30-0)*(7-0)÷(10-0)+0
8	24.0	(30-0)*(8-0)÷(10-0)+0
9	27.0	(30-0)*(9-0)÷(10-0)+0
10	30.0	(30-0)*(10-0)÷(10-0)+0

As shown in the above formula, when measuring 5V, current DC0-10Vvoltage is 15m/s.

2. conductivity and DC0-10Vvoltage computing relationship

For example, the range is $0\sim360^\circ$, the analog output is $0\sim10V$ DC0-10Vvoltage signal, conductivity and DC0-10Vvoltage The calculation relationship is as shown in the formula: C = (A2-A1) * (X-B1) / (B2-B1) + A1, where A2 is conductivity range upper limit, A1 is the lower limit of the range, B2 is DC0-10Vvoltage output range upper limit, B1 is the lower limit, X is the currently read conductivity value, and C is the calculated DC0-10Vvoltage value. The list of commonly used values is as follows:

DC0-10Vvoltage(V)	conductivityValue (°)	Calculation Process
0	0.0	(360-0)*(0-0)÷(10-0)+0
1	36.0	(360-0)*(1-0)÷(10-0)+0



2	72.0	(360-0)*(2-0)÷(10-0)+0
3	108.0	(360-0)*(3-0)÷(10-0)+0
4	144.0	(360-0)*(4-0)÷(10-0)+0
5	180.0	(360-0)*(5-0)÷(10-0)+0
6	216.0	(360-0)*(6-0)÷(10-0)+0
7	252.0	(360-0)*(7-0)÷(10-0)+0
8	288.0	(360-0)*(8-0)÷(10-0)+0
9	324.0	(360-0)*(9-0)÷(10-0)+0
10	360.0	(360-0)*(10-0)÷(10-0)+0

As shown in the above formula, when measuring 5V, current DC0-10Vvoltage is 180 $^\circ$ $^\circ$

Disclaimer

This document provides all information about the product, does not grant any license to intellectual property, does not express or imply, and prohibits any other means of granting any intellectual property rights, such as the statement of sales terms and conditions of this product, other issues. No liability is assumed. Furthermore, our company makes no warranties, express or implied, regarding the sale and use of this product, including the suitability for the specific use of the product, the marketability or the infringement liability for any patent, copyright or other intellectual property rights, etc. Product specifications and product descriptions may be modified at any time without notice.

Contact Us

Company: Shanghai Sonbest Industrial Co., Ltd TRANBALL Brand Division Address:Building 8,No.215 North east road,Baoshan District,Shanghai,China

Web: http://www.qunbao.com Web: http://www.tranball.com

SKYPE: soobuu

Email: sale@sonbest.com

Tel: 86-021-51083595 / 66862055 / 66862075 / 66861077